



- 1) Load Impulse.wav
- 2) Read Impulse.wav while recording Tonedexter's output on a 2nd channel MUTED
- 3) On the 2nd channel you will get the Impulse Response.



- 4) Trim the silence at the beginning of your IR file.
- 5) Normalize & save that track into a wav file